



**Barefoot International & Fly High Mfg.**  
**3879 North Richards Street**  
**Milwaukee, WI 53212**

**Phone: 414-964-3668 / 800-932-0685 Fax: 414-964-5767**  
**E-Mail: bifh@mindspring.com Web: www.fatsac.com**

## Pro X Series Fat Sacs and Tsunami Pump



**WARNING**



**DO NOT LEAVE SACS UNATTENDED WHILE FILLING • DO NOT EXCEED WEIGHT LIMITS FOR BOAT CAPABILITIES • DO NOT PERFORM SHARP TURNS WHILE USING SACS • ALWAYS USE THE THROTTLE TO COME TO A CONTROLLED STOP ALLOWING BOAT TO PROGRESSIVELY SETTLE IN THE WATER • DO NOT USE DRUGS OR ALCOHOL WHILE USING SACS**

### FILLING YOUR PRO X SERIES SACS

- 1- Attach W730 Female Quick Connect fitting to the sac in desired location. BE SURE NOT TO CROSS THREAD
- 2- Thread W731 Wally Plug fittings into remaining sac valves.
- 3- Attach the W738 Male Quick Connect on the hose to the W730 Female Quick Connect fitting installed in the sac. NOTE: If you are using a garden hose to fill the sac, you must use W732 GHT fitting to connect the hose to the sac
- 4- Place the pump in the water keeping it clear of weeds and sand. Hold pump under water to help prime it.
- 5- Plug the pump into the accessory outlet in your boat. The pump will turn on and begin to fill the sac. If there is no accessory outlet in your boat, you may purchase battery terminal accessory plugs through your dealer.
- 6- Continue to attend the sac while filling. Make any necessary adjustments to the sac while it fills to keep the fittings in an accessible location for draining. NOTE: DO NOT OVER FILL THE SAC
- 7- When filling is complete unplug the pump from the accessory outlet. Quickly disconnect the pump hose from the sac and cap the W730 Female Quick Connect fitting with the W731 Quick Connect Cap.

### DRAINING YOUR PRO X SERIES SACS

- 1- Attach the W734 Male Quick Connect fitting on the bottom of the Tsunami Pump to the W730 Female Quick Connect fitting in the sac.
- 2- Place the hose of the pump over the side of the boat.
- 3- Plug the pump into the accessory outlet to turn it on. You may have to push the pump down into the sac to prime it.

- If using Tsunami Pump to fill other sacs, use W735 and W732 fittings.
- To fill Pro X Series Fat Sacs™ with other pumps or garden hose, use W732 fitting.



**W730 / W739**



**W731**



**W732**



**W734**



**W738**



**W735**



VISIT OUR WEBSITE FOR MORE FITTING OPTIONS AND COMBINATIONS | [WWW.FATSAC.COM](http://WWW.FATSAC.COM)